

Siemens Low-Voltage Code Decoder — 3RT, 3RV, 3RU, 3VA, 5SL and 3SU Explained

cBallast Technical Sourcing · LV switchgear and control · issued 2026-10-06 · cballast.com/documents/siemens-lv-code-decoder-3rt-3va-5sl-3su

What the leading groups in Siemens low-voltage order numbers mean — 3RT2 contactors, 3RV motor-protection breakers, 3RU/3RB overload relays, 3VA moulded-case breakers with their 3VA9 accessories, 5SL miniature breakers and 3SU1 pushbuttons — with worked examples from the catalogue and the checks that prevent a wrong panel part.

The family prefixes

Siemens LV order numbers (MLFB codes) start with a family group that instantly places the device:

Prefix | Family | Catalogue example |

3RT2 | SIRIUS power contactors | 3RT2 contactor, 3-pole |

3RH2 | Auxiliary (control) contactors | quoted with the matching 3RT2 |

3RU / 3RB | Thermal / electronic overload relays | sized to the contactor frame |

3RV | Motor-protection circuit breakers | combination starters with 3RT2 |

3VA | SENTRON moulded-case breakers | 3VA9263-0JA12 box terminal (3VA9 = accessories) |

5SL | Miniature circuit breakers | 5SL6363-7 (C63, 3-pole) |

5SV | Residual-current devices | paired with 5SL in distribution boards |

3SU1 | Pushbuttons and pilot devices (Ø22) | 3SU1 label holder |

Worked examples

5SL6363-7 reads as: 5SL = MCB; 6 = the 6 kA breaking-capacity series; the next digits carry pole count and rating — this one is a C-curve 63 A three-pole, exactly as the catalogue row states. Siemens' 5SL4 and 5SL7 siblings shift the breaking capacity (10 kA class and higher) while keeping the logic.

3VA9263-0JA12: 3VA9 marks a SENTRON accessory; the digits that follow bind it to a frame — here a box terminal for the 3VA2 250 A frame, 25–185 mm² (a number so often mistyped as "3VA9463" that the catalogue page lists the misprint). Breaker-side, 3VA1/3VA2 encode frame and breaking class before the trip-unit digits.

3RT2 contactors scale through frame sizes S00–S3 and beyond: the two digits after 3RT2 fix frame and AC-3 rating, the following group the contact complement, and the final letters the coil voltage — always read the coil code from the old unit, not assumed from the panel voltage.

Checks before ordering a replacement

Full MLFB from the device face — dash suffixes change coils, terminals and auxiliaries.

Coil voltage group on contactors; AC and DC coils are different part numbers.

Accessory compatibility by frame: a 3VA9 accessory fits only its stated 3VA frame; the same is true of 3RU overloads on 3RT2 frames.

Breaking capacity class on 5SL/3VA must meet the board's prospective fault current — see the selectivity guide.

Browse the stock base at Siemens electrical components (about 7,000 line items) — quotations within 24 hours, dispatch from European supplier stock.

Frequently asked questions

What does 5SL63 mean on a Siemens MCB? 5SL = miniature circuit breaker, 6 = the 6 kA series; the following digits give poles and rating — 5SL6363-7 is the C-curve 63 A three-pole in that series. What is the difference between 3RT and 3RH?

3RT2 are power contactors for motor and load switching; 3RH2 are auxiliary contactors for control logic — same SIRIUS platform, different duty. Which overload relay fits a 3RT2 contactor? A 3RU (thermal) or 3RB (electronic) sized to the same SIRIUS frame — frame match first, then the current setting range around the motor's rated current. What does 3VA9 mean?

Accessory for the SENTRON 3VA breaker family — terminals, locks, auxiliaries — each bound to a specific frame size stated in its description. Can I order from a partial Siemens number? Send what the nameplate shows: the family group usually survives even on worn labels, and the quotation confirms the full MLFB against frame, coil and accessory data.

Part numbers and designations are those of the original manufacturers and are given for identification. cBallast is an independent supplier. © cBallast 2026 · cballast.com