

Head-Pressure Control with Water-Regulating Valves — Penn V46

Fresh- and Sea-Water Selection

cBallast Technical Sourcing · Pressure-actuated water valves · issued 2026-10-03 · cballast.com/documents/water-regulating-valves-penn-v46

How a pressure-actuated water-regulating valve holds condensing pressure on water-cooled plants, selecting Penn V46 sizes 3/8" to 2", why sea-water service requires the bronze B-versions, setting procedure and the fouling maintenance that keeps them modulating.

What the valve does

On a water-cooled condenser, the V46 throttles cooling-water flow in response to refrigerant head pressure: a bellows senses discharge pressure and opens the water port progressively as pressure rises. Result: condensing pressure stays near setpoint across load and water-temperature swings, water is not wasted at low load, and flow stops entirely when the compressor stops (no standby water bleed). It is the simplest, most reliable head-pressure control a water-cooled plant can carry — no electronics, nothing to configure but the setpoint spring.

Fresh water vs sea water

The catalogue stocks both lines: A-versions for fresh/tower/well water — V46AA 3/8", V46AD 1", V46AR 1 1/2", V46SA 3/8" — and B-versions in naval bronze for sea water: V46BB 1/2", V46BC 3/4", V46BD 1", V46BS 2". Standard-body valves in sea water dezincify and seize; on marine reefer plant, fishing vessels and coastal process cooling the bronze versions are not an upgrade but the requirement.

Selection

Size by flow, not pipe: from the condenser's design water flow at the available pressure drop (valve capacity tables), then check it matches the line; an oversized valve hunts at low load.

Pressure range: the actuating range must bracket the refrigerant's design condensing pressure — ranges differ per model variant; match the refrigerant and setpoint window from the data sheet.

Sensing connection: the capillary taps the compressor discharge/receiver inlet side; protect it with a damping loop on reciprocating plants (1.5 m loop).

Direction and strainer: flow arrow honoured, and a serviceable strainer upstream on anything but drinking-grade water — sea-water installs want duplex strainers you can swap at sea.

Setting procedure

With the plant at stable load: read condensing pressure, turn the adjusting spring until the target is held (typical HFC medium-temp fresh-water plants condense ~ +35...40 °C equivalent; marine sea-water plants per the plant manual), then verify behaviour at the extremes — valve closed with compressor off, fully opening at high load. Record the setpoint in the plant log. A valve that cannot reach setpoint either lacks water (strainer, pump, scaled condenser) or is undersized; do not chase it with the spring.

Maintenance

The failure mode is fouling, not wear: scale and biofilm on the seat make the valve pass at standstill (standby water consumption, over-condensed starts) or stick (head-pressure trips). Annually — quarterly on raw sea water: isolate, dismantle the water side, descale seat and disc, inspect the bellows capillary for corrosion, renew gaskets and reset. Pair the inspection with condenser-tube cleaning; a clean valve on a scaled condenser still can't hold pressure. Where winter sea temperature drops very low, confirm minimum-flow behaviour so condensing pressure doesn't fall below the expansion valve's working minimum — on such plants the V46 is the difference between stable winter operation and morning lockouts.

Part numbers and designations are those of the original manufacturers and are given for identification. cBallast is an independent supplier. © cBallast 2026 · cballast.com