

Installation guide

Shut-off valves


Type SVA-HL 15-150, 65 bar (942 psi)

148R9672


148R9672

Installation


1




2



3




4



Valve size	Bolt*	Nm	LB-feet
DN 15-20	M8x30	22	16
DN 25-50	M10x30	44	32
DN 65	M12x30	74	53
DN 80	M10x30	44	32
DN 100	M12x30	74	53
DN 125-150	M16x40	183	135


*Always use 42CrMo4, DIN 933



5a


5b

Maintenance




Danfoss
A148B168.10

6



Danfoss
A148B169.11

7







Danfoss
A148B170.11

8


DN 15-40

DN 50-150




Danfoss
A148B186.10

9



Danfoss
A148B171.10


10



Danfoss
A148B172.10

11

Valve size	Nm	LB-feet
DN 15-20	40	30
DN 25-40	60	45
DN 50-65	60	45
DN 80-100	100	73
DN 125-150	100	73



Danfoss
A148B173.11

12

ENGLISH

The SVA-HL valve is designed for use in industrial refrigeration systems. The following installation and service instructions should be carefully read and fully understood before using the product or servicing it. Only trained and qualified personnel should be responsible for installation, operation, and service.

Installation

Refrigerants

The valve can be used for all common refrigerants, including H₂S and flammable hydrocarbons and non-corrosive gases or liquids, with due consideration given to valve materials.

Flammable hydrocarbons

If one of the following refrigerants is used: Propane (R 290), Propylene (R1270), Butane (R600), Iso-Butane (R600a), and Ethan (R170) or mixtures of the mentioned refrigerants, please require additional information from Danfoss.

Temperature range

-60/+150 °C (-76/+302 °F)

Pressure range

The valves are designed for a maximum working pressure of 65 bar (942 psig) throughout the temperature range.

Installation

The valve must be installed with the spindle vertically upwards or in horizontal position (fig. 1). Valves should be operated by hand without the use of tools or other devices (fig. 3). The valve is designed to withstand a high internal pressure. However, the piping system should be designed to avoid liquid traps and reduce the risk of hydraulic pressure caused by thermal expansion. It must be ensured that the valve is protected from pressure transients like "liquid hammer" in the system.

Recommended direction of flow

To achieve optimum flow conditions, the valve should be installed with the flow towards the valve cone as indicated by the arrow on the side of the valve body (fig. 2). Flow in the opposite direction is also acceptable (fig. 2), but slightly reduces the k_v / C_v value.

Operation

Avoid overloading the spindle by the inappropriate use of tools (Fig. 3).

Welding

The bonnet should be removed before welding (fig. 4) to prevent damage to the O-rings in the packing gland and between the valve body and bonnet, as well as the teflon gasket in the valve seat.

Only materials and welding methods, compatible with the valve housing material, must be applied to the valve housing. The valve should be cleaned internally to remove welding debris on completion of welding and before the valve is reassembled.

Avoid welding debris and dirt in the threads of the housing and the bonnet.

Removing the bonnet can be omitted provided that: The temperature in the area between the valve body and bonnet during welding does not exceed +150 °C/+302 °F. This temperature depends on the welding method as well as on any cooling of the valve body during the welding itself. (Cooling can be ensured by, for example, wrapping a wet cloth around the valve body.) Make sure that no dirt, welding debris etc. get into the valve during the welding procedure.

Be careful not to damage the teflon cone ring.

The valve housing must be free from stresses (external loads) after installation.

Stop valves must not be mounted in systems where the outlet side of the valve is open to atmosphere. The outlet side of the valve must always be connected to the system or properly capped off, for example with a welded-on end plate.

Assembly

Remove welding debris and any dirt from pipes and valve body before assembly.

During assembly, check:

- that the seal between valve body and top section (pos. A) is undamaged.
- that the valve spindle is unscratched and has not been damaged by impact.
- that the Teflon gasket on the valve cone is undamaged.

Ensure also that the valve cone is screwed back to the top section before refitting the top section in the body (Fig. 5a).

Tightening

Tighten the bonnet with a torque wrench, to the values indicated in the table (fig. 5b).

Tightening of the bonnet should be performed according to sound mechanical practice.

Colour and identification

The SVA-HL valves are painted with a black oxide primer in the factory. Precise identification of the valve is made via the ID ring at the top of the bonnet, as well as by the stamping on the valve body.

The external surface of the valve housing must be prevented against corrosion with a suitable protective coating after installation and assembly.

Protection of the ID ring when repainting the valve is recommended.

Maintenance

Dismantling the valve

The top section must not be removed while the valve is subject to pressure.

Replacing the spindle seal:

During service and maintenance the complete spindle seal can be replaced. Seals can be supplied as spare parts. Normally, the valve should not be subject to pressure when the seal is removed. However, the seal can be removed while there is pressure in the valve if the following precautions are taken:

Reverse sealing (Fig. 6)

The valve is reverse-sealed by turning the spindle anticlockwise until the spindle rotation is blocked.

Pressure equalisation (Fig. 7)

Under certain conditions, pressure can build up behind the spindle seal. This pressure can be equalised by slowly unscrewing the seal. During this operation, it is recommended that a handwheel or other adjusting tool be fitted to the end of the spindle in order to maintain the torque for reverse sealing.

Removing the spindle seal (Fig. 8)

The handwheel and other spindle seal components can now be removed.

Note! Teflon gaskets should not be re-used after removing the spindle seal.

Fitting a replacement spindle seal (Fig. 9)

Great care should be taken when fitting a new spindle seal and damage to Teflon gaskets must be avoided.

During fitting, the individual components in the spindle seal should be placed in order and positioned as shown (Fig. 9).

Replacing the cone (Fig. 10)

Remove the screw (Pos. B) from the cone with a hexagon key.

SVA-HL 15-40 (½-1½")	2 mm a/flats
SVA-HL 50-65 (2-2½")	2.5 mm a/flats
SVA-HL 80-100 (3-4")	4 mm a/flats
SVA-HL 125-150 (5-6")	5 mm a/flats

The bearing balls (Pos. C) can be taken out and the cone subsequently removed.

SVA-HL 15-20 (½-¾")	10 pcs.
SVA-HL 25-65 (1½-2½")	14 pcs.
SVA-HL 80-150 (3-6")	13 pcs.

A new cone can now be mounted on the spindle and the balls replaced. Refit the screw and tighten it. If the cone and spindle are detached several times, it may be necessary to use a strong adhesive (e.g. Loctite no. 648) to ensure screw fixing.

Replacing the reverse sealing, DN 80-150 (3-6") (Fig. 11)

The reverse sealing of the valve is in the form of a special Teflon ring DN 80-150 (3-6"). This Teflon ring should be replaced if it becomes damaged. Screw the spindle out of the top section. Carefully remove the original Teflon ring and fit a replacement on the sloping contact surface just inside the opening in the top section.

Avoid folding or damaging the Teflon ring during fitting. In addition, be careful not to damage the contact surface for the ring in the top section.

Assembly (Fig. 5a)

Remove any dirt from the body before the valve is assembled. Check that the cone has been screwed back towards the bonnet before it is replaced in the valve body.

During assembly, check:

- that the seal between the valve body and top section (pos. A) is undamaged.
- that the valve spindle is unscratched and has not been damaged by impact.
- that the Teflon gasket on the valve cone is undamaged.

Ensure also that the valve cone is screwed back to the top section before refitting the top section in the body (Fig. 5a).

Tightening (Fig. 12)

Tighten the bonnet with a torque wrench, to the values indicated in the table (fig. 5b). Tightening of the bonnet should be performed according to sound mechanical practice.

Tighten the packing gland with a torque wrench, to the values indicated in the table (fig. 12).

If the packing gland is leaking, it is possible to carefully tighten it with a wrench. Make sure not to apply very high force. Danfoss recommend turning the packing gland in steps and to check the leaking between each step.

Use only original Danfoss parts, including packing glands, O-rings and gaskets for replacement. Materials of new parts are certified for the relevant refrigerant.

In cases of doubt, please contact Danfoss.

Danfoss A/S

Climate Solutions • danfoss.com • +45 7488 2222

Any information, including, but not limited to information on selection of product, its application or use, product design, weight, dimensions, capacity or any other technical data in product manuals, catalogues descriptions, advertisements, etc. and whether made available in writing, orally, electronically, online or via download, shall be considered informative, and is only binding if and to the extent, explicit reference is made in a quotation or order confirmation. Danfoss cannot accept any responsibility for possible errors in catalogues, brochures, videos and other material. Danfoss reserves the right to alter its products without notice. This also applies to products ordered but not delivered provided that such alterations can be made without changes to form, fit or function of the product.

All trademarks in this material are property of Danfoss A/S or Danfoss group companies. Danfoss and the Danfoss logo are trademarks of Danfoss A/S. All rights reserved.