Laser Shaft Alignment — Tools, Tolerances and Method

cBallast Technical Sourcing · Shaft alignment systems · issued 2026-11-09 · cballast.com/documents/laser-shaft-alignment-tools-tolerances

Shaft alignment for coupled machines: why misalignment is the leading root cause of seal, bearing and coupling failures, offset and angularity defined, typical alignment tolerances by speed, dial indicators against laser systems, soft foot and thermal growth, the correction workflow, and the SKF TKSA and Fluke 830 instrument tiers with a tolerance table to work to.

The short version

Misalignment is the quiet machine-killer. A coupled pump or fan running misaligned loads bearings and seals radially every revolution: premature bearing failures, leaking mechanical seals, hot couplings, broken shafts and vibration alarms trace back to alignment more often than to any other single cause. Alignment done to tolerance is the cheapest reliability work there is.

Two numbers define it: parallel offset (mm between shaft centrelines at the coupling) and angularity (mm per 100 mm of gap, the slope between shafts) — each in the horizontal and vertical plane. A complete alignment states four values, not "it looked fine".

Tolerance shrinks as speed rises. Working figures used across industry: at 1500 rpm about 0.09 mm acceptable offset (0.06 excellent); at 3000 rpm about 0.06 mm (0.03 excellent); angularity similarly halving as speed doubles. The machine maker's or coupling maker's own table, where published, overrules the generic one.

Lasers beat dials for speed and error-proofing, not physics. A skilled millwright with two dial indicators reaches the same truth; the laser system removes bar sag, reading errors and arithmetic, measures with a fraction-of-a-turn sweep, and documents the result — which is why even small plants standardised on entry laser kits (SKF TKSA 11 class) and up.

Soft foot first, always. A machine rocking on one foot bends its casing when bolted: check and correct soft foot (≤ 0.05 mm per foot is the working rule) before measuring alignment, or every number that follows is fiction.

Align for the running condition. Machines grow with temperature: hot pumps and turbines are deliberately set misaligned cold by the maker's thermal-growth offsets so they run true hot. The data plate or manual figure goes into the laser tool as a target, not zero.

1. What misalignment does, measurably

Flexible couplings tolerate misalignment; they do not erase it. The reaction forces pass into the shafts and bearings of both machines, rising roughly in proportion to the misalignment and the coupling's stiffness. Field experience and maker studies agree on the pattern: seal life falls steeply with offset (mechanical seals are routinely quoted as failing at several times their design rate on poorly aligned sets), bearing life follows the load cubed (a 20% load increase from misalignment halves L10 life — the arithmetic is in our bearing selection guide), couplings wear their elements and lock up, and the vibration spectrum shows the classic 2x running-speed signature. The payback case writes itself: one avoided seal change on a process pump funds a mid-tier alignment system.

2. Offset, angularity and the tolerance table

Speed (rpm) | Offset — acceptable (mm) | Offset — excellent (mm) | Angularity — acceptable (mm/100 mm) | Angularity — excellent (mm/100 mm) |

750 | 0.19 | 0.09 | 0.13 | 0.09 |

1500 | 0.09 | 0.06 | 0.07 | 0.05 |

3000 | 0.06 | 0.03 | 0.04 | 0.03 |

6000 | 0.03 | 0.02 | 0.03 | 0.02 |

These are the general-purpose figures for short flexible couplings as used in laser-tool firmware and industry references; spacer couplings get their own (gentler) tables, and cardan shafts their own method. Precedence order when numbers conflict: machine maker, then coupling maker, then the generic table. Record which table the job was closed against — "within tolerance" means nothing without naming the tolerance.

3. Instruments: dials to laser tiers

Tier | Instrument class | What it buys |

Dial indicators (rim & face / reverse dial) | Two dials, brackets, arithmetic | Lowest cost, works anywhere; demands skill, sag correction and time; no built-in documentation |

Entry laser | SKF TKSA 11 class | Guided measurement from partial shaft turn, live correction values, phone/app reporting — the dial replacement for standard pump sets |

Mid laser | SKF TKSA 41, Fluke 830 class | Larger detectors (more misalignment range), soft-foot and thermal target workflows, machine-train basics, rugged displays |

Advanced laser | SKF TKSA 71 class (Easy-Laser and Pruftechnik top ranges equivalent) | Long-distance and high-resolution detectors, machine trains, cardan and vertical machines, full reporting suites — the contractor and fleet tier |

Choosing between tiers is a use-pattern question, the same arithmetic as videoscopes: a site aligning its own standard pump sets monthly lives happily at entry/mid tier; alignment-as-a-service, machine trains and hot-alignment programmes justify the top tier. All tiers assume shafts that can be rotated together; where one shaft cannot turn, the method changes (single-laser

to coupling face) and the mid tiers up handle it.

4. The workflow that produces a real alignment

Pre-checks. Lockout; coupling condition (a worn element masks alignment); pipe strain released (a pump pulled by its pipework cannot be aligned — flange fit-up is a piping job, see the flange references); base and shim condition — rusted shim packs are replaced, not reused.

Soft foot. Measure at each foot with the system or a dial; correct to ≤ 0.05 mm with clean stainless shims under the whole foot, not corner slivers.

Measure. Mount brackets, enter dimensions (coupling diameter and gap, foot distances), sweep the shafts; the tool outputs offset and angularity in both planes.

Correct vertical first (shims under the movable machine — calculated by the tool per foot), then horizontal (jacking screws beat hammer blows), re-measure after each move.

Thermal targets. Enter the maker's cold offsets so the hot running condition lands on zero.

Document. As-found and as-left values, tolerance table used, thermal targets, shim map. The report is the asset — it is what turns the next vibration alarm into a ten-minute diagnosis.

5. Related geometry work

Belt-driven machines are aligned too — pulley alignment tools and the belt tensions in our V-belt guide govern there, and a misaligned belt drive eats belts instead of bearings. Couplings themselves are selected and inspected per our coupling types guide; bearings damaged by past misalignment are identified by their wear pattern before replacement (bearing designation guide), and mounted correctly with induction heaters rather than flame. On vessels, engine-to-gearbox and shaft-line alignment is a class-involved discipline with its own procedures — the pump-set practice in this guide is the transferable foundation.

How buying works at cballast. We quote alignment systems by tier with brackets, extension chains and cases itemised, shim stock in the standard sizes alongside, and successor models when an installed system's sensors are no longer serviceable. Accounts are vetted at onboarding; first order prepaid; established accounts on credit terms with repeat discounts; public bodies and utilities invoiced against purchase order from the first order. RFQs to sales@cballast.com.

Frequently asked questions

What is an acceptable shaft alignment tolerance?Speed-dependent: for short flexible couplings, about 0.09 mm offset at 1500 rpm and 0.06 mm at 3000 rpm as "acceptable", roughly halved for "excellent", with angularity limits alongside (see the table above). The machine or coupling maker's own figures take precedence where published.
What is soft foot and why does it come first?A foot that does not sit flat on its base: bolting it down distorts the casing, moves bearings and invalidates every alignment reading. Check each foot (loosen, measure movement), correct to within about 0.05 mm with full-footprint shims, then align. It is the most common reason "aligned" machines still vibrate.
Are dial indicators still acceptable for alignment?Yes — reverse-dial alignment done well is as accurate as a laser. The laser buys speed, bracket-sag immunity, guided arithmetic, less skill dependence and a stored report. For anything beyond occasional standard pump sets, the entry laser tier repays itself in hours saved per job.
What is thermal growth compensation?Machines change height and position as they heat: a hot pump or turbine aligned to zero cold runs misaligned hot. Makers publish cold-setting offsets (or they are measured hot once); these go into the alignment tool as targets so the running condition, not the cold condition, is aligned.
How often should alignment be checked?After any seal, bearing or coupling change, after the machine has been moved or piped, after a failure investigation — and periodically on critical sets (annually is a common default). Trend it: a set that will not hold alignment is reporting a foundation, grout or pipe-strain problem.
Who supplies SKF TKSA and Fluke 830 alignment systems?cballast.com quotes the SKF TKSA tiers, Fluke 830 and the equivalent Easy-Laser and Pruftechnik classes with brackets and accessories, plus shim stock, against the machines actually in service. Describe the machine park to sales@cballast.com.

References and related guides

Sources referenced: general alignment tolerance tables as published in laser-system documentation (SKF TKSA, Fluke 830, Easy-Laser, Pruftechnik); ANSI/ASA S2.75 shaft alignment methodology; coupling makers' misalignment ratings; ISO 10816/20816 vibration evaluation context.

Shaft coupling types — jaw, pin, bush

Centrifugal pump curves, duty point and NPSH

Rolling bearing selection (ISO 15)

V-belt size chart SPZ/SPA/SPB/SPC

Grundfos CR pump overhaul kits

Questions on a tier, a bracket set or a tolerance: write to sales@cballast.com. We answer whether or not you buy from us.

Part numbers and designations are those of the original manufacturers and are given for identification. cBallast is an independent supplier. © cBallast 2026 · cballast.com