Loctite Activators & Primers — 7649, 7471, 7063, SF 770

cBallast Technical Sourcing · Surface preparation for adhesives · issued 2026-11-09 · cballast.com/documents/loctite-primers-activators-cleaners-7649-7471-7063

The surface-preparation half of the Loctite system decoded: Activator 7649 and Primer 7471 for anaerobics on passive metals and cold workshops, Cleaner 7063 as the universal degrease step, SF 770 and 7239 primers for polyolefins and difficult plastics under cyanoacrylates, 7455 for instant-adhesive cure speed — when each is mandatory rather than nice-to-have, on-part life, cure-time effects, and the cross-reference logic to Weicon and Permatex surface prep.

The short version

Anaerobic adhesives (threadlockers, retaining compounds, sealants) cure by metal contact in the absence of air. Active metals — plain steel, copper, brass, iron — trigger the cure by themselves. Passive surfaces — stainless steel, zinc and other platings, anodized aluminium, titanium, oxide layers — do not, or cure too slowly to trust. That is what the activators exist for.
The two anaerobic activators: Loctite SF 7649 (Activator / Primer N) — solvent-based, the general-purpose choice for passive metals, cold conditions (below ~5 °C) and faster fixture; and Loctite SF 7471 (Primer T) — the variant for larger bond gaps and slower-curing products. Both flash off in a minute or two and leave an on-part life measured in days if parts are kept clean.
Everything starts with 7063: SF 7063 cleaner/degreaser is the residue-free step before any bonding or locking — oil, cutting fluid and preservation film beat any adhesive chemistry, activator or not.
Plastics have their own primers: SF 770 makes polyolefins (PP, PE) and similar low-energy plastics bondable with cyanoacrylates — without it, superglue simply peels off these materials.
Activator is not a crutch for bad practice: it compensates surface chemistry, not contamination, wrong product choice or excessive gap. The decision table below says when it is mandatory, when optional, and when the answer is a different adhesive — cross-checked against our Loctite selection chart and equivalents chart.

1. The product table

Product | Role | Chemistry class | Use with | Catalogue anchors |

SF 7649 (Activator N) | Cure activator for anaerobics on passive metals; cold-weather cure; faster fixturing | Solvent-borne copper-complex activator | Threadlockers (243/270 class), retaining compounds (638/648 class), anaerobic sealants (577/518 class) | SF 7649 aerosol; 7649 150 ml |

SF 7471 (Primer T) | Activator variant for larger gaps and slow formulations | Solvent-borne activator | Retaining and sealing anaerobics at the top of their gap range | SF 7471 aerosol; 7471 150 ml |

SF 7063 | Cleaner/degreaser, residue-free | Solvent blend, flash-off | Before every anaerobic, CA or epoxy bond; before activator | SF 7063 400 ml |

SF 770 | Polyolefin primer for cyanoacrylates | Aliphatic amine in solvent | CAs (401/406 class) on PP, PE, POM, silicone rubber | SF 770 10 g |

SF 7455 (accelerator) | Speeds cyanoacrylate cure, fills the "blooming/slow joint" gap | Solvent-borne CA accelerator | CAs on acidic or dry surfaces, gap fills, low humidity | Quoted on request with CA lines |

SF 7240 class | Solvent-free anaerobic activator where VOC rules bite | Solvent-free activator | Anaerobics in enclosed workshops | Quoted on request |

Naming note for requisitions: Henkel's current names carry the SF prefix (SF 7649), older stock and drawings say "Activator N" or just 7649 — one product family across the names. State the number; we match the vintage.

2. When activator is mandatory, optional, or the wrong answer

Situation | Verdict | Why |

Threadlocker or retainer on stainless, zinc-plated, galvanized, anodized or chromated parts | Mandatory | Passive surfaces lack the metal ions that start the anaerobic cure — uncured liquid in the joint is a loose bolt with extra steps |

Workshop or deck below ~5 °C | Mandatory in practice | Anaerobic cure slows drastically with cold; activator restores usable fixture times |

Retaining compound at the top of its gap range (worn bore, repair bush) | Use 7471 | Large gaps starve the cure of surface contact; Primer T is formulated for exactly this |

Plain steel bolt and nut, warm workshop, normal gap | Optional | Active metal cures on its own; activator only buys speed — handling in minutes instead of hours |

One bonding partner active (steel), one passive (stainless) | Activate the passive side | One active surface is often enough, but activating the passive partner removes the gamble |

Oily, painted or corroded parts | Wrong answer — clean first | Activator is chemistry, not detergent; 7063 then activator then adhesive is the order |

Gap beyond the adhesive's rated maximum even with 7471 | Wrong answer — change method | Bush and re-machine, or move to a higher-gap product per the selection chart |

Superglue on polypropylene / polyethylene | SF 770, not 7649 | Different problem (surface energy, not passivity) — polyolefin primer is the only thing that works |

3. Method — the two-minute discipline that decides the joint

1. Clean: flood the threads or bore with 7063, brush if crusted, let it flash off dry — no wiping with shop rags that redeposit oil. 2. Activate: spray or brush a thin film of 7649 (or 7471 per the table) on the passive surface; let the solvent flash at least ~1 minute — bonding onto wet activator solvates the adhesive and weakens the joint. Activated parts hold their readiness for days when kept clean and dry, so batch preparation is fine. 3. Apply the adhesive per its own instructions — fill 360° on retaining joints, on-thread ring for threadlockers — and assemble within the adhesive's open time. 4. Respect fixture vs full cure: activator shortens fixture (handling) time dramatically, but full chemical strength still wants its hours; do not pressure-test or torque-load a 518-class flange sealant five minutes after assembly because the activator made it feel solid.

One honest warning the datasheets also carry: activator can slightly reduce ultimate strength on already-active metals (the cure races, the polymer network forms less densely). On plain steel with time available, skip it; on passive metals there is no trade-off to weigh — without it there is no reliable cure at all.

4. Cross-reference thinking — Weicon, Permatex and the generics

Function | Loctite | Peer-class examples | Caveat |

Anaerobic activator, general | SF 7649 | Weicon AN activator class; Permatex surface prep / activator class | Match to the adhesive maker where warranty or approval matters — activators are tuned to their own resin systems |

Anaerobic activator, large gap | SF 7471 | Peer "slow-cure/large-gap" activators | Gap claims differ by maker; the adhesive's datasheet rules |

Residue-free cleaner | SF 7063 | Weicon Cleaner S class, brake-cleaner grade solvents | "Residue-free" is the spec that matters; citrus or oily cleaners sabotage the bond |

Polyolefin primer | SF 770 | Peer polyolefin primers (3M class) | Pair primer and CA from one system where possible |

The deeper cross-reference tables for the adhesives themselves — threadlocker grades, retaining compounds, flange sealants across Loctite, Weicon, Permatex and ThreeBond — live in our Loctite cross-reference chart and the four-brand equivalents guide. The rule here is the rule there: an equivalent matches chemistry class, strength grade, gap and approvals — not just the colour of the liquid.

5. Buying — sizes, shelf life, and what to put on the RFQ

Activators come as aerosols (the workshop default — even film, no contaminated brushes) and bottles for metered dispensing; cleaners as aerosols; SF 770 in small bottles because a little primes a lot. Shelf life runs in the 1–2 year class from manufacture, stored cool — date-code stock on receipt, and on ships order the size the job consumes within a season rather than a drum that expires. A complete RFQ line: product number, size, quantity, and the adhesive it partners (so we can flag a mismatch — 770 ordered for an anaerobic job, or 7649 for polypropylene). Typical pairings from the catalogue: Loctite 243 or the 243-class equivalent with 7649 for stainless fastener work; Loctite 638 with 7649 or 7471 for bearing and bush retention.

How buying works at cballast. We quote the Henkel Loctite programme and vetted equivalents side by side, with surface-prep lines added where the joint needs them — and flagged when they are missing from an inquiry that clearly needs them (stainless threadlocking without activator is the classic). Accounts are vetted at onboarding; first order prepaid; established accounts on credit terms with repeat discounts; public bodies and utilities invoiced against purchase order from the first order. RFQs to sales@cballast.com.

Frequently asked questions

What is Loctite 7649 used for?It is an activator (Primer/Activator N) for anaerobic adhesives — threadlockers, retaining compounds, thread and flange sealants. It triggers cure on passive surfaces (stainless, platings, anodized aluminium), restores cure speed in cold conditions, and shortens fixture time generally. Spray, let flash off about a minute, then apply the adhesive.
What is the difference between Loctite 7649 and 7471?Both activate anaerobic cure; 7649 (Activator N) is the general-purpose choice, 7471 (Primer T) is formulated for larger bond gaps and the slower-curing products. For stainless fasteners either does the job; for a worn bore repaired with a retaining compound near its gap limit, use 7471.
Do I need an activator for Loctite on stainless steel?Yes, in any joint you care about. Stainless is a passive metal: anaerobic adhesives cure on it unreliably or extremely slowly on their own. 7649 on the threads, one minute flash-off, then the threadlocker — that is the manufacturer's own method, not an upsell.
Does activator weaken the adhesive?On passive metals, no — it is the difference between curing and not curing. On already-active metals it can trade a little ultimate strength for much faster fixturing; where maximum strength matters more than speed on plain steel, cure unactivated and give it the full time.
What is Loctite 7063 and when do I use it?A residue-free cleaner/degreaser used before bonding, locking or sealing — and before activator. Oil and preservation films defeat adhesives regardless of activator chemistry; 7063 flashes off and leaves nothing behind, which shop rags and general degreasers do not.
How do I glue polypropylene or polyethylene?Prime with Loctite SF 770 (polyolefin primer), then use a suitable cyanoacrylate within the primer's open time. Without the primer, CAs do not wet these low-energy plastics and the bond peels. 7649 does not help here — different problem, different product.
Is there a Loctite 7649 equivalent?Peer activators exist in the Weicon and Permatex systems and work on the same principle. Where an approval, warranty or critical joint is involved, pair activator and adhesive from the same maker; elsewhere a class-equivalent activator is acceptable. Our cross-reference chart maps the families, and we state the class per line when quoting.
Who supplies Loctite activators and primers?cballast.com quotes the full surface-prep programme — 7649, 7471, 7063, SF 770 and partners — alongside the adhesives themselves, with pairing checked per line. Write to sales@cballast.com.

References and related guides

Standards and sources referenced: Henkel Loctite technical data sheets (SF 7649, SF 7471, SF 7063, SF 770, SF 7455) and the Loctite worldwide design handbook's surface-preparation guidance; peer manufacturers' (Weicon, Permatex) surface-prep documentation.

Loctite cross-reference & equivalents chart

Loctite adhesive selection chart

Loctite / Weicon / Permatex / ThreeBond cross-reference

Metric fastener property classes — ISO 898 / ISO 3506

Gasket material selection guide

Questions on an activator pairing or a cure problem on a specific joint: write to sales@cballast.com. We answer whether or not you buy from us.

Part numbers and designations are those of the original manufacturers and are given for identification. cBallast is an independent supplier. © cBallast 2026 · cballast.com