

# Balancing Valve Finder — Danfoss AB-QM, ASV-PV / ASV-M, USV-I / USV-M, MSV-BD / MSV-F2, IMI TA STAD / STAF, Frese by DN and Type

cBallast Technical Sourcing · generated 2026-09-29 · cballast.com/documents/balancing-valve-finder-danfoss-ab-qm-asv-pv-asv-m-usv-msv-bd-ta-stad-frese-by-dn-and-type · first 418 rows; the full table is online

Hydronic balancing valves fall into three groups: manual (static) balancing valves with a presetting scale and measuring points (Danfoss MSV-BD, MSV-F2, USV-I, LENO MSV-B; IMI TA STAD, STAF, STAP), automatic differential-pressure controllers that hold a constant 9G across a riser (ASV-PV with partner valve ASV-M or ASV-I; TA STAP), and pressure-independent balancing and control valves that combine flow limitation with a control valve for an actuator (Danfoss AB-QM in DN 10–250, Frese OPTIMA, TA KTM). Selection is by DN, design flow or Kv, connection (internal or external thread, flanged PN 16/25) and the 9G range of the controller. The finder lists the catalogue by family and DN with the version and connection so a valve of the same function and size can be quoted.

| Section                                                         | DN    | Version / setting | Connection      | Part number | Brand   |
|-----------------------------------------------------------------|-------|-------------------|-----------------|-------------|---------|
| Danfoss AB-QM pressure-independent balancing and control valves | DN 10 | LF, accessory     | press           | 003Z1251    | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 10 | LF, accessory     | press           | 003Z1261    | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 10 | LF, accessory     | press           | 003Z1281    | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 10 | accessory         | external thread | 003Z0231    | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 10 | accessory         | —               | 003Z0392    | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 10 | accessory         | press           | 003Z1201    | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 10 | accessory         | press           | 003Z1211    | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 10 | accessory         | —               | 003Z1236    | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15 | HF, accessory     | press           | 003Z1222    | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15 | LF, accessory     | press           | 003Z1252    | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15 | LF, accessory     | press           | 003Z1262    | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15 | Low flow          | —               | 003Z1238    | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15 | accessory         | weld ends       | 003Z0226    | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15 | accessory         | external thread | 003Z0232    | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15 | accessory         | press           | 003Z1202    | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15 | accessory         | press           | 003Z1212    | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15 | accessory         | weld ends       | 003Z1271    | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15 | —                 | —               | 003Z1242    | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15 | —                 | —               | 003Z8524    | Danfoss |

|                                                                 |       |               |                 |          |         |
|-----------------------------------------------------------------|-------|---------------|-----------------|----------|---------|
| Danfoss AB-QM pressure-independent balancing and control valves | DN 20 | HF, accessory | press           | 003Z1223 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 20 | accessory     | weld ends       | 003Z0227 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 20 | accessory     | external thread | 003Z0233 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 20 | accessory     | press           | 003Z1203 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 20 | accessory     | press           | 003Z1213 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 20 | accessory     | weld ends       | 003Z1272 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 20 | —             | —               | 003Z1243 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 25 | HF, accessory | press           | 003Z1224 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 25 | accessory     | weld ends       | 003Z0228 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 25 | accessory     | external thread | 003Z0234 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 25 | accessory     | —               | 003Z0393 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 25 | accessory     | press           | 003Z1204 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 25 | accessory     | press           | 003Z1214 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 25 | accessory     | weld ends       | 003Z1273 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 25 | —             | —               | 003Z0294 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 25 | —             | —               | 003Z1244 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 32 | HF, accessory | press           | 003Z1225 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 32 | accessory     | weld ends       | 003Z0229 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 32 | accessory     | external thread | 003Z0235 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 32 | accessory     | press           | 003Z1205 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 32 | accessory     | press           | 003Z1215 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 32 | accessory     | weld ends       | 003Z1274 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 32 | —             | —               | 003Z1245 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 32 | —             | —               | 003Z0215 | Danfoss |

|                                                                 |       |           |                 |          |         |
|-----------------------------------------------------------------|-------|-----------|-----------------|----------|---------|
| Danfoss AB-QM pressure-independent balancing and control valves | DN 40 | accessory | weld ends       | 003Z0270 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 40 | accessory | weld ends       | 003Z0271 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 40 | accessory | —               | 003Z0273 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 40 | accessory | external thread | 003Z0279 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 40 | accessory | weld ends       | 003Z1275 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 40 | —         | —               | 003Z0695 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 40 | —         | external thread | 003Z0770 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 40 | —         | external thread | 003Z1770 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 50 | accessory | weld ends       | 003Z0272 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 50 | accessory | —               | 003Z0274 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 50 | accessory | weld ends       | 003Z0276 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 50 | accessory | external thread | 003Z0278 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 50 | accessory | weld ends       | 003Z1276 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 50 | —         | external thread | 003Z0771 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 50 | —         | flanged         | 003Z0772 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 50 | —         | flanged         | 003Z0962 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 50 | —         | external thread | 003Z1771 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 50 | —         | flanged PN 16   | 003Z1772 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 65 | HF        | flanged PN 16   | 003Z1793 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 65 | high-flow | flanged         | 003Z0793 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 65 | —         | flanged         | 003Z0773 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 65 | —         | flanged         | 003Z0963 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 65 | —         | flanged PN 16   | 003Z1773 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 80 | HF        | flanged PN 16   | 003Z1794 | Danfoss |

|                                                                 |        |           |               |          |         |
|-----------------------------------------------------------------|--------|-----------|---------------|----------|---------|
| Danfoss AB-QM pressure-independent balancing and control valves | DN 80  | high-flow | flanged       | 003Z0794 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 80  | —         | flanged       | 003Z0774 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 80  | —         | flanged PN 16 | 003Z1774 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 100 | HF        | flanged PN 16 | 003Z1795 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 100 | high-flow | flanged       | 003Z0795 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 100 | —         | flanged       | 003Z0775 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 100 | —         | flanged       | 003Z0965 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 100 | —         | flanged PN 16 | 003Z1775 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 125 | HF        | flanged PN 16 | 003Z1715 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 125 | high-flow | flanged       | 003Z0715 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 125 | high-flow | flanged       | 003Z0735 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 125 | —         | —             | 003Z0696 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 125 | —         | flanged       | 003Z0705 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 125 | —         | flanged       | 003Z0725 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 125 | —         | flanged PN 16 | 003Z1705 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 150 | HF        | flanged PN 16 | 003Z1716 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 150 | high-flow | flanged       | 003Z0716 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 150 | high-flow | flanged       | 003Z0736 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 150 | —         | flanged       | 003Z0706 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 150 | —         | flanged       | 003Z0726 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 150 | —         | flanged PN 16 | 003Z1706 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 200 | HF        | flanged PN 16 | 003Z1717 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 200 | high-flow | flanged       | 003Z0717 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 200 | high-flow | flanged       | 003Z0737 | Danfoss |

|                                                                 |        |                         |                 |          |         |
|-----------------------------------------------------------------|--------|-------------------------|-----------------|----------|---------|
| Danfoss AB-QM pressure-independent balancing and control valves | DN 200 | —                       | —               | 003Z0697 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 200 | —                       | flanged         | 003Z0707 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 200 | —                       | flanged         | 003Z0727 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 200 | —                       | flanged PN 16   | 003Z1707 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 250 | HF                      | flanged PN 16   | 003Z1718 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 250 | high-flow               | flanged         | 003Z0718 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 250 | high-flow               | flanged         | 003Z0738 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 250 | —                       | flanged         | 003Z0708 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 250 | —                       | flanged         | 003Z0728 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 250 | —                       | flanged PN 16   | 003Z1708 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15  | HF, gen. 4.0, accessory | press           | 003Z1622 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15  | HF, gen. 4.0, accessory | press           | 003Z1632 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15  | HF, gen. 4.0, accessory | press           | 003Z1722 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15  | HF, gen. 4.0, accessory | press           | 003Z1732 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15  | HF, gen. 4.0, accessory | external thread | 003Z8202 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15  | HF, gen. 4.0, accessory | external thread | 003Z8222 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15  | HF, gen. 4.0, accessory | internal thread | 003Z8302 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15  | HF, gen. 4.0, accessory | internal thread | 003Z8322 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15  | LF, gen. 4.0, accessory | press           | 003Z1620 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15  | LF, gen. 4.0, accessory | press           | 003Z1630 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15  | LF, gen. 4.0, accessory | press           | 003Z1720 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15  | LF, gen. 4.0, accessory | press           | 003Z1730 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15  | LF, gen. 4.0, accessory | external thread | 003Z8200 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15  | LF, gen. 4.0, accessory | external thread | 003Z8220 | Danfoss |

|                                                                 |       |                         |                 |          |         |
|-----------------------------------------------------------------|-------|-------------------------|-----------------|----------|---------|
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15 | LF, gen. 4.0, accessory | internal thread | 003Z8300 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15 | LF, gen. 4.0, accessory | internal thread | 003Z8320 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15 | gen. 4.0, accessory     | press           | 003Z1621 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15 | gen. 4.0, accessory     | press           | 003Z1631 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15 | gen. 4.0, accessory     | press           | 003Z1721 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15 | gen. 4.0, accessory     | press           | 003Z1731 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15 | gen. 4.0, accessory     | external thread | 003Z8201 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15 | gen. 4.0, accessory     | external thread | 003Z8221 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15 | gen. 4.0, accessory     | internal thread | 003Z8301 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15 | gen. 4.0, accessory     | internal thread | 003Z8321 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15 | low-flow, gen. 4.0      | internal thread | 003Z1560 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15 | low-flow, gen. 4.0      | press           | 003Z1580 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15 | normal-flow, gen. 4.0   | internal thread | 003Z1561 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 15 | normal-flow, gen. 4.0   | press           | 003Z1581 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 20 | HF, gen. 4.0, accessory | press           | 003Z1624 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 20 | HF, gen. 4.0, accessory | press           | 003Z1634 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 20 | HF, gen. 4.0, accessory | press           | 003Z1724 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 20 | HF, gen. 4.0, accessory | press           | 003Z1734 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 20 | HF, gen. 4.0, accessory | external thread | 003Z8204 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 20 | HF, gen. 4.0, accessory | external thread | 003Z8224 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 20 | HF, gen. 4.0, accessory | internal thread | 003Z8304 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 20 | HF, gen. 4.0, accessory | internal thread | 003Z8324 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 20 | gen. 4.0, accessory     | press           | 003Z1623 | Danfoss |
| Danfoss AB-QM pressure-independent balancing and control valves | DN 20 | gen. 4.0, accessory     | press           | 003Z1633 | Danfoss |

|                                                                 |       |                      |                 |          |         |
|-----------------------------------------------------------------|-------|----------------------|-----------------|----------|---------|
| Danfoss AB-QM pressure-independent balancing and control valves | DN 20 | gen. 4.0, accessory  | press           | 003Z1723 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 15 | —                    | internal thread | 003L7621 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 15 | —                    | external thread | 003L7626 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 20 | —                    | internal thread | 003L7622 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 20 | —                    | external thread | 003L7627 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 25 | —                    | internal thread | 003L7623 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 25 | —                    | external thread | 003L7628 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 32 | —                    | internal thread | 003L7624 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 32 | —                    | external thread | 003L7629 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 40 | —                    | internal thread | 003L7625 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 40 | —                    | external thread | 003L7630 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 15 | 20–40 kPa, accessory | —               | 003L8246 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 15 | 20–60 kPa, gen. 4G   | internal thread | 003Z5541 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 15 | 20–60 kPa, gen. 4G   | external thread | 003Z5551 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 15 | 5–25 kPa             | press           | 003Z5686 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 15 | 5–25 kPa             | press           | 003Z5695 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 15 | 5–25 kPa, gen. 4G    | internal thread | 003Z5501 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 15 | 5–25 kPa, gen. 4G    | external thread | 003Z5511 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 15 | 5–25 kPa, gen. 4G    | internal thread | 003Z5601 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 15 | 5–25 kPa, gen. 4G    | external thread | 003Z5611 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 15 | 5–25 kPa, gen. 4G    | internal thread | 003Z5621 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 20 | 20–40 kPa, accessory | —               | 003L8247 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 20 | 20–60 kPa, gen. 4G   | internal thread | 003Z5542 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 20 | 20–60 kPa, gen. 4G   | external thread | 003Z5552 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 20 | 5–25 kPa             | press           | 003Z5687 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 20 | 5–25 kPa             | press           | 003Z5696 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 20 | 5–25 kPa, gen. 4G    | internal thread | 003Z5502 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 20 | 5–25 kPa, gen. 4G    | external thread | 003Z5512 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 20 | 5–25 kPa, gen. 4G    | internal thread | 003Z5602 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 20 | 5–25 kPa, gen. 4G    | external thread | 003Z5612 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 20 | 5–25 kPa, gen. 4G    | internal thread | 003Z5622 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 25 | 20–40 kPa, accessory | —               | 003L8248 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 25 | 20–60 kPa, gen. 4G   | internal thread | 003Z5543 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 25 | 20–60 kPa, gen. 4G   | external thread | 003Z5553 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 25 | 5–25 kPa             | press           | 003Z5688 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 25 | 5–25 kPa             | press           | 003Z5697 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 25 | 5–25 kPa, gen. 4G    | internal thread | 003Z5503 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 25 | 5–25 kPa, gen. 4G    | external thread | 003Z5513 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers        | DN 25 | 5–25 kPa, gen. 4G    | internal thread | 003Z5603 | Danfoss |

|                                                          |       |                      |                 |          |         |
|----------------------------------------------------------|-------|----------------------|-----------------|----------|---------|
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 25 | 5–25 kPa, gen. 4G    | external thread | 003Z5613 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 25 | 5–25 kPa, gen. 4G    | internal thread | 003Z5623 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 32 | 20–40 kPa, accessory | —               | 003L8249 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 32 | 20–60 kPa, gen. 4G   | internal thread | 003Z5544 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 32 | 20–60 kPa, gen. 4G   | external thread | 003Z5554 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 32 | 5–25 kPa             | press           | 003Z5689 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 32 | 5–25 kPa             | press           | 003Z5698 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 32 | 5–25 kPa, gen. 4G    | internal thread | 003Z5504 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 32 | 5–25 kPa, gen. 4G    | external thread | 003Z5514 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 32 | 5–25 kPa, gen. 4G    | internal thread | 003Z5604 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 32 | 5–25 kPa, gen. 4G    | external thread | 003Z5614 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 40 | 20–60 kPa, gen. 4G   | internal thread | 003Z5545 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 40 | 20–60 kPa, gen. 4G   | external thread | 003Z5555 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 40 | 5–25 kPa             | press           | 003Z5690 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 40 | 5–25 kPa             | press           | 003Z5699 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 40 | 5–25 kPa, gen. 4G    | internal thread | 003Z5505 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 40 | 5–25 kPa, gen. 4G    | external thread | 003Z5515 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 40 | 5–25 kPa, gen. 4G    | internal thread | 003Z5605 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 40 | 5–25 kPa, gen. 4G    | external thread | 003Z5615 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 50 | 20–40 kPa, gen. 3G   | external thread | 003Z0621 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 50 | 20–40 kPa, gen. 3G   | flanged         | 003Z0626 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 50 | 20–60 kPa, gen. 4G   | internal thread | 003Z5546 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 50 | 20–60 kPa, gen. 4G   | external thread | 003Z5556 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 50 | 35–75 kPa, gen. 3G   | external thread | 003Z0631 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 50 | 5–25 kPa, gen. 3G    | external thread | 003Z0611 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 50 | 5–25 kPa, gen. 4G    | internal thread | 003Z5506 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 50 | 5–25 kPa, gen. 4G    | external thread | 003Z5516 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 50 | 5–25 kPa, gen. 4G    | internal thread | 003Z5606 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 50 | 5–25 kPa, gen. 4G    | external thread | 003Z5616 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 50 | 60–100 kPa, gen. 3G  | external thread | 003Z0641 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 50 | 60–100 kPa, gen. 3G  | flanged         | 003Z0646 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 50 | —                    | —               | 003Z5700 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 65 | 100–130 kPa, gen. 3G | flanged         | 003Z0651 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 65 | 120–160 kPa, gen. 3G | flanged         | 003Z0654 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 65 | 20–40 kPa, gen. 3G   | flanged         | 003Z0623 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 65 | 35–75 kPa, gen. 3G   | flanged         | 003Z0633 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 65 | 60–100 kPa, gen. 3G  | flanged         | 003Z0643 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 80 | 100–130 kPa, gen. 3G | flanged         | 003Z0652 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 80 | 120–160 kPa, gen. 3G | flanged         | 003Z0655 | Danfoss |

|                                                          |        |                      |                 |          |         |
|----------------------------------------------------------|--------|----------------------|-----------------|----------|---------|
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 80  | 20–40 kPa, gen. 3G   | flanged         | 003Z0624 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 80  | 35–75 kPa, gen. 3G   | flanged         | 003Z0634 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 80  | 60–100 kPa, gen. 3G  | flanged         | 003Z0644 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 100 | 100–130 kPa, gen. 3G | flanged         | 003Z0653 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 100 | 120–160 kPa, gen. 3G | flanged         | 003Z0657 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 100 | 20–40 kPa, gen. 3G   | flanged         | 003Z0625 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 100 | 35–75 kPa, gen. 3G   | flanged         | 003Z0635 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 100 | 60–100 kPa, gen. 3G  | flanged         | 003Z0645 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 125 | 70–150 kPa, gen. 3G  | flanged         | 003Z0656 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 150 | 70–150 kPa, gen. 3G  | flanged         | 003Z0666 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 200 | 70–150 kPa, gen. 3G  | flanged         | 003Z0676 | Danfoss |
| Danfoss ASV-PV / ASV-P differential pressure controllers | DN 250 | 70–150 kPa, gen. 3G  | flanged         | 003Z0686 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves            | DN 15  | —                    | internal thread | 003Z4041 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves            | DN 20  | —                    | internal thread | 003Z4042 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves            | DN 25  | —                    | internal thread | 003Z4043 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves            | DN 32  | —                    | internal thread | 003Z4044 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves            | DN 40  | —                    | internal thread | 003Z4045 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves            | DN 50  | —                    | internal thread | 003Z4046 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves            | DN 15  | —                    | internal thread | 003L7641 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves            | DN 15  | —                    | external thread | 003L7646 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves            | DN 15  | —                    | —               | 003L8155 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves            | DN 20  | —                    | internal thread | 003L7642 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves            | DN 20  | —                    | external thread | 003L7647 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves            | DN 20  | —                    | —               | 003L8156 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves            | DN 25  | —                    | internal thread | 003L7643 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves            | DN 25  | —                    | external thread | 003L7648 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves            | DN 25  | —                    | —               | 003L8157 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves            | DN 32  | —                    | internal thread | 003L7644 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves            | DN 32  | —                    | external thread | 003L7649 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves            | DN 32  | —                    | —               | 003L8158 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves            | DN 40  | —                    | internal thread | 003L7645 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves            | DN 40  | —                    | external thread | 003L7650 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves            | DN 50  | —                    | external thread | 003L7652 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves            | DN 15  | —                    | internal thread | 003L7681 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves            | DN 15  | —                    | internal thread | 003L7691 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves            | DN 15  | —                    | external thread | 003L7696 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves            | DN 15  | —                    | —               | 003L8146 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves            | DN 20  | —                    | internal thread | 003L7682 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves            | DN 20  | —                    | internal thread | 003L7692 | Danfoss |

|                                               |       |       |                 |          |         |
|-----------------------------------------------|-------|-------|-----------------|----------|---------|
| Danfoss ASV-M / ASV-I / ASV-BD partner valves | DN 20 | —     | external thread | 003L7697 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves | DN 20 | —     | —               | 003L8147 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves | DN 25 | —     | internal thread | 003L7683 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves | DN 25 | —     | internal thread | 003L7693 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves | DN 25 | —     | external thread | 003L7698 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves | DN 25 | —     | —               | 003L8148 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves | DN 32 | —     | internal thread | 003L7684 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves | DN 32 | —     | internal thread | 003L7694 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves | DN 32 | —     | external thread | 003L7699 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves | DN 32 | —     | —               | 003L8149 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves | DN 40 | —     | internal thread | 003L7685 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves | DN 40 | —     | internal thread | 003L7695 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves | DN 40 | —     | external thread | 003L7700 | Danfoss |
| Danfoss ASV-M / ASV-I / ASV-BD partner valves | DN 50 | Kv 16 | external thread | 003L7702 | Danfoss |
| Danfoss USV manual balancing valves           | DN 15 | —     | flanged PN 16   | 003Z2131 | Danfoss |
| Danfoss USV manual balancing valves           | DN 15 | —     | flanged PN 16   | 003Z2136 | Danfoss |
| Danfoss USV manual balancing valves           | DN 20 | —     | flanged PN 16   | 003Z2132 | Danfoss |
| Danfoss USV manual balancing valves           | DN 20 | —     | flanged PN 16   | 003Z2137 | Danfoss |
| Danfoss USV manual balancing valves           | DN 25 | —     | flanged PN 16   | 003Z2133 | Danfoss |
| Danfoss USV manual balancing valves           | DN 25 | —     | flanged PN 16   | 003Z2138 | Danfoss |
| Danfoss USV manual balancing valves           | DN 32 | —     | flanged PN 16   | 003Z2134 | Danfoss |
| Danfoss USV manual balancing valves           | DN 32 | —     | flanged PN 16   | 003Z2139 | Danfoss |
| Danfoss USV manual balancing valves           | DN 40 | —     | flanged PN 16   | 003Z2135 | Danfoss |
| Danfoss USV manual balancing valves           | DN 40 | —     | flanged PN 16   | 003Z2140 | Danfoss |
| Danfoss USV manual balancing valves           | DN 50 | —     | flanged PN 16   | 003Z2151 | Danfoss |
| Danfoss USV manual balancing valves           | DN 50 | —     | flanged PN 16   | 003Z2152 | Danfoss |
| Danfoss USV manual balancing valves           | DN 15 | —     | flanged PN 16   | 003Z2121 | Danfoss |
| Danfoss USV manual balancing valves           | DN 15 | —     | flanged PN 16   | 003Z2126 | Danfoss |
| Danfoss USV manual balancing valves           | DN 15 | —     | flanged PN 16   | 003Z2141 | Danfoss |
| Danfoss USV manual balancing valves           | DN 15 | —     | flanged PN 16   | 003Z2146 | Danfoss |
| Danfoss USV manual balancing valves           | DN 15 | —     | —               | 003Z2156 | Danfoss |
| Danfoss USV manual balancing valves           | DN 20 | —     | flanged PN 16   | 003Z2122 | Danfoss |
| Danfoss USV manual balancing valves           | DN 20 | —     | flanged PN 16   | 003Z2127 | Danfoss |
| Danfoss USV manual balancing valves           | DN 20 | —     | flanged PN 16   | 003Z2142 | Danfoss |
| Danfoss USV manual balancing valves           | DN 20 | —     | flanged PN 16   | 003Z2147 | Danfoss |
| Danfoss USV manual balancing valves           | DN 20 | —     | —               | 003Z2157 | Danfoss |
| Danfoss USV manual balancing valves           | DN 25 | —     | flanged PN 16   | 003Z2123 | Danfoss |
| Danfoss USV manual balancing valves           | DN 25 | —     | flanged PN 16   | 003Z2128 | Danfoss |
| Danfoss USV manual balancing valves           | DN 25 | —     | flanged PN 16   | 003Z2143 | Danfoss |

|                                            |       |                      |                 |          |         |
|--------------------------------------------|-------|----------------------|-----------------|----------|---------|
| Danfoss USV manual balancing valves        | DN 25 | —                    | flanged PN 16   | 003Z2148 | Danfoss |
| Danfoss USV manual balancing valves        | DN 25 | —                    | —               | 003Z2158 | Danfoss |
| Danfoss USV manual balancing valves        | DN 32 | —                    | flanged PN 16   | 003Z2124 | Danfoss |
| Danfoss USV manual balancing valves        | DN 32 | —                    | flanged PN 16   | 003Z2129 | Danfoss |
| Danfoss USV manual balancing valves        | DN 32 | —                    | flanged PN 16   | 003Z2144 | Danfoss |
| Danfoss USV manual balancing valves        | DN 32 | —                    | flanged PN 16   | 003Z2149 | Danfoss |
| Danfoss USV manual balancing valves        | DN 32 | —                    | —               | 003Z2159 | Danfoss |
| Danfoss USV manual balancing valves        | DN 40 | —                    | flanged PN 16   | 003Z2125 | Danfoss |
| Danfoss USV manual balancing valves        | DN 40 | —                    | flanged PN 16   | 003Z2130 | Danfoss |
| Danfoss USV manual balancing valves        | DN 40 | —                    | flanged PN 16   | 003Z2145 | Danfoss |
| Danfoss USV manual balancing valves        | DN 40 | —                    | flanged PN 16   | 003Z2150 | Danfoss |
| Danfoss USV manual balancing valves        | DN 50 | —                    | flanged PN 16   | 003Z2153 | Danfoss |
| Danfoss USV manual balancing valves        | DN 50 | —                    | flanged PN 16   | 003Z2154 | Danfoss |
| Danfoss USV manual balancing valves        | DN 50 | —                    | flanged PN 16   | 003Z2155 | Danfoss |
| Danfoss USV manual balancing valves        | DN 50 | —                    | flanged PN 16   | 003Z2160 | Danfoss |
| Danfoss USV manual balancing valves        | DN 15 | —                    | flanged PN 16   | 003Z2231 | Danfoss |
| Danfoss USV manual balancing valves        | DN 20 | —                    | flanged PN 16   | 003Z2232 | Danfoss |
| Danfoss USV manual balancing valves        | DN 25 | —                    | flanged PN 16   | 003Z2233 | Danfoss |
| Danfoss USV manual balancing valves        | DN 32 | —                    | flanged PN 16   | 003Z2234 | Danfoss |
| Danfoss USV manual balancing valves        | DN 40 | —                    | flanged PN 16   | 003Z2235 | Danfoss |
| Danfoss USV manual balancing valves        | DN 50 | —                    | flanged PN 16   | 003Z2236 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 15 | Kv 3, 3 m³/h         | internal thread | 003Z7001 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 15 | LF, Kv 2.5, 2.5 m³/h | internal thread | 003Z7000 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 15 | Low Flow             | internal thread | 003Z4000 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 15 | Low Flow             | internal thread | 003Z4020 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 15 | Low Flow             | external thread | 003Z4100 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 15 | Low Flow             | external thread | 003Z4130 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 15 | —                    | internal thread | 003Z4001 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 15 | —                    | internal thread | 003Z4011 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 15 | —                    | internal thread | 003Z4021 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 15 | —                    | internal thread | 003Z4031 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 15 | —                    | external thread | 003Z4101 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 15 | —                    | external thread | 003Z4111 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 15 | —                    | external thread | 003Z4131 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 15 | —                    | internal thread | 003Z4051 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 20 | Kv 6, 6 m³/h         | internal thread | 003Z7002 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 20 | —                    | internal thread | 003Z4002 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 20 | —                    | internal thread | 003Z4012 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 20 | —                    | internal thread | 003Z4022 | Danfoss |

|                                            |       |                  |                 |          |         |
|--------------------------------------------|-------|------------------|-----------------|----------|---------|
| Danfoss MSV / LENO manual balancing valves | DN 20 | —                | internal thread | 003Z4032 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 20 | —                | external thread | 003Z4102 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 20 | —                | external thread | 003Z4112 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 20 | —                | internal thread | 003Z4052 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 25 | Kv 9.5, 9.5 m³/h | internal thread | 003Z7003 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 25 | —                | internal thread | 003Z4003 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 25 | —                | internal thread | 003Z4013 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 25 | —                | internal thread | 003Z4023 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 25 | —                | internal thread | 003Z4053 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 32 | Kv 18, 18 m³/h   | internal thread | 003Z7004 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 32 | —                | internal thread | 003Z4004 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 32 | —                | internal thread | 003Z4014 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 32 | —                | internal thread | 003Z4024 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 32 | —                | internal thread | 003Z4054 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 40 | Kv 26, 26 m³/h   | internal thread | 003Z7005 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 40 | —                | internal thread | 003Z4005 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 40 | —                | internal thread | 003Z4015 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 40 | —                | internal thread | 003Z4025 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 40 | —                | internal thread | 003Z4055 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 50 | Kv 40, 40 m³/h   | internal thread | 003Z7006 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 50 | —                | internal thread | 003Z4006 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 50 | —                | internal thread | 003Z4016 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 50 | —                | internal thread | 003Z4026 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 50 | —                | internal thread | 003Z4056 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 15 | —                | flanged PN 16   | 003Z1085 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 15 | —                | flanged PN 25   | 003Z1092 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 20 | —                | flanged PN 16   | 003Z1086 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 20 | —                | flanged PN 25   | 003Z1093 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 25 | —                | flanged PN 16   | 003Z1087 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 25 | —                | flanged PN 25   | 003Z1094 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 32 | —                | flanged PN 16   | 003Z1088 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 32 | —                | flanged PN 25   | 003Z1095 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 40 | —                | flanged PN 16   | 003Z1089 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 40 | —                | flanged PN 25   | 003Z1096 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 50 | accessory        | —               | 003Z0179 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 50 | —                | flanged PN 16   | 003Z1061 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 50 | —                | flanged PN 25   | 003Z1070 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 65 | accessory        | —               | 003Z0180 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 65 | —                | flanged PN 16   | 003Z1062 | Danfoss |

|                                            |        |           |                 |          |         |
|--------------------------------------------|--------|-----------|-----------------|----------|---------|
| Danfoss MSV / LENO manual balancing valves | DN 65  | —         | flanged PN 25   | 003Z1071 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 80  | —         | flanged PN 16   | 003Z1063 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 80  | —         | flanged PN 25   | 003Z1072 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 100 | —         | flanged PN 16   | 003Z1064 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 100 | —         | flanged PN 25   | 003Z1073 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 125 | —         | flanged PN 16   | 003Z1065 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 125 | —         | flanged PN 25   | 003Z1074 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 150 | —         | flanged PN 16   | 003Z1066 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 150 | —         | flanged PN 25   | 003Z1075 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 200 | accessory | —               | 003Z0181 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 200 | accessory | —               | 003Z1180 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 200 | —         | flanged PN 16   | 003Z1067 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 200 | —         | flanged PN 25   | 003Z1076 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 200 | —         | flanged PN 16   | 003Z1140 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 200 | —         | flanged PN 25   | 003Z1145 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 250 | accessory | —               | 003Z0182 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 250 | —         | flanged PN 16   | 003Z1068 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 250 | —         | flanged PN 25   | 003Z1077 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 250 | —         | flanged PN 16   | 003Z1141 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 250 | —         | flanged PN 25   | 003Z1146 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 300 | —         | flanged PN 16   | 003Z1069 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 300 | —         | flanged PN 25   | 003Z1078 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 300 | —         | flanged PN 16   | 003Z1142 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 300 | —         | flanged PN 25   | 003Z1147 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 350 | accessory | —               | 003Z0183 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 350 | —         | flanged PN 16   | 003Z1090 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 350 | —         | flanged PN 25   | 003Z1097 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 350 | —         | flanged PN 16   | 003Z1143 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 350 | —         | flanged PN 25   | 003Z1148 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 400 | accessory | —               | 003Z1183 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 400 | —         | flanged PN 16   | 003Z1091 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 400 | —         | flanged PN 25   | 003Z1098 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 400 | —         | flanged PN 16   | 003Z1144 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 400 | —         | flanged PN 25   | 003Z1149 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 15  | accessory | —               | 003Z4210 | Danfoss |
| Danfoss MSV / LENO manual balancing valves | DN 32  | accessory | —               | 003Z4211 | Danfoss |
| Other makes and families                   | DN 15  | —         | internal thread | 003Z4080 | Danfoss |
| Other makes and families                   | DN 20  | —         | internal thread | 003Z4082 | Danfoss |
| Other makes and families                   | DN 50  | —         | internal thread | 003Z4086 | Danfoss |

|                          |        |           |   |          |         |
|--------------------------|--------|-----------|---|----------|---------|
| Other makes and families | DN 10  | —         | — | 003Z8504 | Danfoss |
| Other makes and families | DN 40  | —         | — | 003Z8540 | Danfoss |
| Other makes and families | DN 125 | accessory | — | 003Z8561 | Danfoss |
| Other makes and families | DN 125 | accessory | — | 003Z8562 | Danfoss |
| Other makes and families | DN 125 | —         | — | 003Z8560 | Danfoss |
| Other makes and families | DN 200 | —         | — | 003Z8563 | Danfoss |

Part numbers and designations are those of the original manufacturers and are given for identification. cBallast is an independent supplier. © cBallast 2026 · cballast.com