

DIN-Rail Terminal Block Cross-Reference — Phoenix Contact, Weidmüller, WAGO, Schneider Electric, Eaton, ABB by Cross-Section and Type

cBallast Technical Sourcing · generated 2026-09-29 · cballast.com/documents/din-rail-terminal-block-cross-reference-phoenix-contact-weidmuller-wago-schneider-eaton-abb-by-cross-section-and-type · first 118 rows; the full table is online

DIN-rail terminals are matched by nominal cross-section (1.5, 2.5, 4, 6, 10, 16, 35 mm² and up), function (feed-through, protective-earth with rail contact, double- or triple-level, fuse holder, disconnect / test, diode or component blocks) and connection technology (screw, tension spring, push-in). Phoenix Contact UT / ST / PT, Weidmüller WDU / ZDU / A-series, WAGO TOPJOB S 2000 series, Schneider Linergy TR, Eaton XT and ABB SNK ranges all cover the same functions in each cross-section, so an equivalent block can be found by matching those three properties. The table lists the catalogue by type and cross-section with one column per make.

Cross-section · connection	Phoenix Contact	Weidmüller	WAGO	Schneider Electric	Eaton	ABB
Feed-through terminal blocks · 0.14 mm² · n/s	—	9028240000, 9028250000	—	—	—	—
Feed-through terminal blocks · 0.5 mm² · n/s	—	9037200000, 9037400000, 9019020000, 0409500000	—	—	—	—
Feed-through terminal blocks · 0.75 mm² · n/s	—	9019060000, 9004770000, 9037420000, 9202830000, 09018570000	—	—	—	—
Feed-through terminal blocks · 1 mm² · n/s	—	0372600000, 9019070000, 00409700000, 9019110000, 09026080000	—	—	—	—
Feed-through terminal blocks · 1.5 mm² · n/s	QTC 1,5, FBS 5-4, FBS 10-4, FBS 3-4, FBS 4-4	9037480000, 9019430000, 9005890000, 9037490000, 9019130000	—	—	—	—
Feed-through terminal blocks · 1.5 mm² · push-in	PT 1,5/S, PT 1,5/S-QUATTRO BU, PT 1,5/S BU, PT 1,5/S-TWIN, PT 1,5/S-QUATTRO	1988260000, 1552690000, 2816930000, 1552790000, 2464750000	—	—	—	—
Feed-through terminal blocks · 1.5 mm² · screw	MT 1,5	1031480000	—	—	—	—
Feed-through terminal blocks · 1.5 mm² · spring	ST 1,5-QUATTRO BU, ST 1,5-TWIN, ST 1,5 BU, ST 1,5	—	—	—	—	—
Feed-through terminal blocks · 2.5 mm² · n/s	FBS 10-5, FBS 2-5, FBS 20-5, PTI 2,5-L/L, FBS 3-5	9025430000, 9037510000, 2902380000, 0373000000, 9021240000	—	—	—	—
Feed-through terminal blocks · 2.5 mm² · push-in	3209522, PT 2,5-TWIN, PT 2,5-MT, PT 2,5 BU, PT 2,5-QUATTRO	2503880000, 2847330000, 2428520000	—	NSYTRP24, NSYTRP22BL, NSYTRP24BL, NSYTRP22, NSYTRP24D	—	—
Feed-through terminal blocks · 2.5 mm² · screw	3044076, UT 2,5, UTTB 2,5, UT 2,5 BU, UK 2,5 N	1020000000, 1783820000, 0380480000, 01068040000	—	—	—	—
Feed-through terminal blocks · 2.5 mm² · spring	ST 2,5, ST 2,5 BU, ST 2,5-3L, ST 2,5/ 1P	1608510000, 1772060000, 1712750000, 1608580000	—	NSYTRR26T, NSYTRR22BL, NSYTRR23	—	—
Feed-through terminal blocks · 3 mm² · screw	UK 3 N BU, UK 3 N, UK 3-TWIN	—	—	—	—	—
Feed-through terminal blocks · 4 mm² · n/s	FBS 10-6, FBS 20-6, FBS 3-6, FBS 2-6, FBS 50-6	A2C 4 BL, A2C 4, 09026010000, 2874840000, 2874870000	—	—	—	—
Feed-through terminal blocks · 4 mm² · push-in	3211773, PT 4 BU	2581790000, 2460130000, 2871990000, 2459010000, 2871870000	—	NSYTRP42, NSYTRP42BL, NSYTRP44, NSYTRP44BL, NSYTRP43BL	—	—
Feed-through terminal blocks · 4 mm² · screw	3044102, UT 4, UT 4 BU, UK 4 BU, UT 4-TWIN	1020100000	—	—	—	—

Feed-through terminal blocks · 4 mm ² · spring	ST 4, ST 4-QUATTRO BU, ST 4-TWIN, ST 4-QUATTRO	ZDU 4-2/3AN	—	NSYTRR44, NSYTRR43, NSYTRR42BL	—	—
Feed-through terminal blocks · 5 mm ² · push-in	—	2464730000	—	—	—	—
Feed-through terminal blocks · 5 mm ² · screw	3004362, UK 5 N, UK 5 N BU	—	—	—	—	—
Feed-through terminal blocks · 6 mm ² · n/s	FBS 2-8, FBS 10-8, FBS 5-8, FBS 6-8, FB 10- 8-EX	A2C 6, A2C 6 BL, 9037560000, 09019220000, 9037550000	2007-8875, 2007-8873	—	—	—
Feed-through terminal blocks · 6 mm ² · push-in	PT 6 BU	1991780000, 1988130000, 2623910000	—	—	—	—
Feed-through terminal blocks · 6 mm ² · screw	UK 6 N, UT 6, UT 6 BU, UK 5-MTK, UK 6 N BU	—	—	—	—	—
Feed-through terminal blocks · 6 mm ² · spring	ST 6-TWIN, ST 6	—	—	NSYTRR63, NSYTRR62BL, NSYTRR62	—	—
Feed-through terminal blocks · 10 mm ² · n/s	FBS 5-10, FBS 2-10, 0203247, XTV 10 BU, XTV 10	9037570000, 9037340000	—	—	—	—
Feed-through terminal blocks · 10 mm ² · push-in	PT 10 BU, PT 10	2503900000, 1988180000, 1988190000	—	—	—	—
Feed-through terminal blocks · 10 mm ² · screw	3005099, UT 10, UT 10 BU, UK 10 N, UK 10 N BU	1020200000, 3039104240	—	—	—	—
Feed-through terminal blocks · 10 mm ² · spring	ST 10	ZDU 10, ZDU 10 BL	—	NSYTRR102	—	—
Feed-through terminal blocks · 16 mm ² · n/s	FBS 2-12, XTV 16, XTV 16 BU	0492500000, 9037590000, 9037730000	—	—	AKU16/5, AKU16/10	—
Feed-through terminal blocks · 16 mm ² · push-in	PT 16 N BU	2494100000	—	—	—	—
Feed-through terminal blocks · 16 mm ² · screw	3006043, UT 16, UT 16 BU, UK 16 N, UK 16 N BU	—	—	—	—	—
Feed-through terminal blocks · 16 mm ² · spring	ST 16	ZDU 16	—	NSYTRR162	—	—
Feed-through terminal blocks · 35 mm ² · n/s	FBS 2-16, FBI 3-15, FBI 2-15	0317300000, 9019310000	—	—	AKU35/5, AKU35/10	2CCA183465R0001
Feed-through terminal blocks · 35 mm ² · push-in	—	2552090000, 2551510000	—	—	—	—
Feed-through terminal blocks · 35 mm ² · screw	UT 35, UT 35 BU, UK 35 BU, UK 35 N	—	—	—	—	—
Feed-through terminal blocks · 35 mm ² · spring	ST 35 BU, ST 35	—	—	—	—	—
Feed-through terminal blocks · 50 mm ² · n/s	FBI 3-20, FBI 2-20	—	—	—	BPZ-IC/50-16/235-P, BPZ-IC/50-16/235-P-II, BPZ-IC/50-16/235-N	ZK150
Feed-through terminal blocks · 70 mm ² · n/s	—	9028200000	—	—	Y7-107190, AKU70/10	—
Feed-through terminal blocks · 70 mm ² · push-in	—	2663250000	—	—	—	—
Feed-through terminal blocks · 70 mm ² · screw	—	9512190000	—	—	—	—
Feed-through terminal blocks · 95 mm ² · n/s	AGK 10-UKH 95	—	—	—	—	—
Feed-through terminal blocks · 95 mm ² · push-in	PTPOWER 95	—	—	—	—	—
Feed-through terminal blocks · 95 mm ² · screw	UKH 95	—	—	—	—	—
Feed-through terminal blocks · 120 mm ² · n/s	—	—	—	—	AKU120/10, AKU120/5	—
Feed-through terminal blocks · 150 mm ² · n/s	—	—	—	—	EML26	—
Feed-through terminal blocks · 150 mm ² · screw	UKH 150	—	—	—	—	—
Feed-through terminal blocks · 240 mm ² · n/s	—	—	—	33640	—	—

Feed-through terminal blocks · 240 mm² · screw	UKH 240	—	—	—	—	—
Ground / PE terminal blocks · 1.5 mm² · n/s	QTC 1,5-TWIN-PE, QTC 1,5-PE	—	—	—	—	—
Ground / PE terminal blocks · 1.5 mm² · push-in	PT 1,5/S-PE, PT 1,5/S-QUATTRO-PE, PT 1,5/S-PE/L/L, PT 1,5/S-3PE, PT 1,5/S-TWIN-PE	—	—	—	—	—
Ground / PE terminal blocks · 1.5 mm² · spring	ST 1,5-PE, ST 1,5-TWIN-PE, STTB 1,5-PE	—	—	—	—	—
Ground / PE terminal blocks · 2 mm² · screw	—	WPE 2.5N	—	—	—	—
Ground / PE terminal blocks · 2.5 mm² · n/s	UTTB 2,5-PE, QTC 2,5-PE, USLKG 2,5, USLKG 2,5 N, UTI 2,5-PE/L/N	A2C 2.5 PE	—	—	—	—
Ground / PE terminal blocks · 2.5 mm² · push-in	PT 2,5-PE, PTTB 2,5-PE, PT 2,5-QUATTRO-PE, PT 2,5-TWIN-PE, PT 2,5-PE/L/N	—	2003-6645, 2003-7646, 2002-3227, 2002-2207	NSYTRP23PE, NSYTRP22PE, NSYTRP24DPE, NSYTRP24PE	—	—
Ground / PE terminal blocks · 2.5 mm² · screw	UT 2,5-PE, UT 2,5-TWIN-PE, UT 2,5-QUATTRO-PE	WPE 2.5	—	—	—	—
Ground / PE terminal blocks · 2.5 mm² · spring	ST 2,5-QUATTRO-PE, ST 2,5-TWIN-PE, ST 2,5-PE, STTB 2,5-PE, ST 2,5-3PE	ZPE 2.5, ZPE 2.5/4AN	—	NSYTRR23PE, NSYTRR24DPE, NSYTRR22PE	—	—
Ground / PE terminal blocks · 3 mm² · n/s	USLKG 3	—	—	—	—	—
Ground / PE terminal blocks · 4 mm² · n/s	AKG 4 GNYE-EX, PTI 4-PE/L/N, UTTB 4-PE	—	—	—	—	—
Ground / PE terminal blocks · 4 mm² · push-in	PT 4-PE, PT 4-QUATTRO-PE, PT 4-TWIN-PE	—	—	NSYTRP42PE	—	—
Ground / PE terminal blocks · 4 mm² · screw	UT 4-PE, UT 4-QUATTRO-PE, UT 4-TWIN-PE, UT 4-MTD-PE/S, UT 4-HEDI-P/P	1010100000, WPE 4	—	—	—	—
Ground / PE terminal blocks · 4 mm² · spring	ST 4-PE, ST 4-TWIN-PE, ST 4-QUATTRO-PE	ZPE 4	—	NSYTRR42PE, NSYTRR44DPE	—	—
Ground / PE terminal blocks · 5 mm² · n/s	0441504, USLKG 5	—	—	—	—	—
Ground / PE terminal blocks · 5 mm² · screw	UK 5-TWIN-PE	—	—	—	—	—
Ground / PE terminal blocks · 6 mm² · n/s	USLKG 6 N, XTV 6-QUATTRO-PE, XTV 6-TWIN-PE	—	—	—	—	—
Ground / PE terminal blocks · 6 mm² · push-in	PT 6-PE	—	—	—	—	—
Ground / PE terminal blocks · 6 mm² · screw	UT 6-PE	WPE 6	—	—	—	—
Ground / PE terminal blocks · 6 mm² · spring	ST 6-TWIN-PE, ST 6-PE	ZPE 6	—	—	—	—
Ground / PE terminal blocks · 10 mm² · n/s	USLKG 10 N, XTV 10-PE, XTV 10-TWIN-PE	—	—	—	—	—
Ground / PE terminal blocks · 10 mm² · push-in	PT 10-PE, PT 6-TWIN-PE	—	—	—	—	—
Ground / PE terminal blocks · 10 mm² · screw	UT 10-PE, UK 10-TWIN-PE	WPE 10	—	—	—	—
Ground / PE terminal blocks · 10 mm² · spring	ST 10-PE	ZPE 10	—	—	—	—
Ground / PE terminal blocks · 16 mm² · n/s	USLKG 16 N	—	—	—	—	—
Ground / PE terminal blocks · 16 mm² · push-in	PT 16 N-PE	—	—	—	—	—
Ground / PE terminal blocks · 16 mm² · screw	UT 16-PE	WPE 16	—	—	—	—

Ground / PE terminal blocks · 16 mm² · spring	ST 16-PE	ZPE 16	—	NSYTRR162PE	—	—
Ground / PE terminal blocks · 35 mm² · n/s	PTPOWER 35-PE, USLKG 35	—	—	—	—	—
Ground / PE terminal blocks · 35 mm² · screw	UT 35-PE	WPE 35	—	—	—	—
Ground / PE terminal blocks · 35 mm² · spring	ST 35-PE	—	—	—	—	—
Ground / PE terminal blocks · 50 mm² · n/s	USLKG 50	—	—	—	—	—
Ground / PE terminal blocks · 70 mm² · n/s	—	—	—	—	—	1SEP408430P0001
Ground / PE terminal blocks · 95 mm² · n/s	USLKG 95, PTPOWER 95-PE	—	—	—	—	—
Ground / PE terminal blocks · 120 mm² · n/s	—	—	—	—	—	NHP 300162R0001
Double-level terminal blocks · 1.5 mm² · spring	STTB 1,5	—	—	—	—	—
Double-level terminal blocks · 2.5 mm² · n/s	UTTB 2,5 BU, UTTB 2,5-PV	—	—	—	—	—
Double-level terminal blocks · 2.5 mm² · push-in	PTTB 2,5 BU, PTTB 2,5-L/N	—	2002-2951	—	—	—
Double-level terminal blocks · 2.5 mm² · screw	UKK 3	1021600000	—	—	—	—
Double-level terminal blocks · 2.5 mm² · spring	STTB 2,5, STTB 2,5 BU	—	—	—	—	—
Double-level terminal blocks · 4 mm² · n/s	UTTB 4	—	—	—	—	—
Double-level terminal blocks · 4 mm² · push-in	PTTB 4, PTTB 4-PV, PTTB 4 BU	—	—	—	—	—
Triple-level terminal blocks · 2.5 mm² · push-in	—	—	2002-3208	—	—	—
Fuse terminal blocks · 2.5 mm² · n/s	QTC 2,5-HESI (5X20)	—	2202-1611, 2202-1711	—	—	—
Fuse terminal blocks · 4 mm² · push-in	PT 4-HESI (5X20), PT 4-HESILED 24 (5X20), PT 4-HESILA 250 (5X20)	—	—	—	—	—
Fuse terminal blocks · 4 mm² · screw	3046032, UT 4-HESI (5X20), UT 4-HESILA 250 (5X20), UT 4-HESILED 24 (5X20)	0474560000	—	—	—	—
Fuse terminal blocks · 4 mm² · spring	ST 4-HESILED 24 (5X20), ST 4-FSI/C, ST 4-HESILA 250 (5X20), ST 4-HESI (6,3X32), ST 4-HESI (5X20)	—	—	—	—	—
Fuse terminal blocks · 5 mm² · screw	UK 5-HESI, UK 5-HESILED 24, UK 5-HESILA 250	—	—	—	—	—
Fuse terminal blocks · 6 mm² · push-in	—	—	2006-1681	—	—	—
Fuse terminal blocks · 6 mm² · screw	UK 6-FSI/C-LED12, UK 6-FSI/C, UK 6-FSI/C-LED24, UT 6-HESILED 24 (6,3X32), UT 6-HESI (6,3X32)	1014400000	—	—	—	—
Fuse terminal blocks · 6.3 mm² · screw	UK 6,3-HESI	—	—	—	—	—
Fuse terminal blocks · 10 mm² · n/s	—	1011300000	—	—	—	—
Fuse terminal blocks · 10 mm² · screw	UK 10-DREHSI/K (5X25), UK 10-DREHSI (5X20), UK 10-DREHSI (6,3X32)	—	—	—	—	—
Disconnect and test terminal blocks · 1.5 mm² · n/s	QTC 1,5-MT	—	—	—	—	—
Disconnect and test terminal blocks · 1.5 mm² · push-in	PT 1,5/S-MT	—	—	—	—	—
Disconnect and test terminal blocks · 2.5 mm² · n/s	MTK, MTK-P/P MED SPERRE, MTK BU	1021500000	—	NSYTRR22SC	—	—

Disconnect and test terminal blocks · 2.5 mm ² · push-in	PT 2,5-MTB, PT 2,5-QUATTRO-MTB, PT 2,5-MT BU, PT 2,5-TG, PT 2,5-TWIN-MT BU	—	—	NSYTRP22TB	—	—
Disconnect and test terminal blocks · 2.5 mm ² · screw	UT 2,5-MT, UT 2,5-MT BU, UT 2,5-MT-P/P, UT 2,5-TG-P/P, UT 2,5-TG	—	—	—	—	—
Disconnect and test terminal blocks · 2.5 mm ² · spring	ST 2,5-MT, ST 2,5-MT BU	—	—	—	—	—
Disconnect and test terminal blocks · 4 mm ² · n/s	PTV 2,5-MT, PTV 2,5-MT BU	—	—	NSYTRV42SCD	—	—
Disconnect and test terminal blocks · 4 mm ² · push-in	PT 4-MT, PTTBS 2,5-2MTB, PT 4-TG	—	—	—	—	—
Disconnect and test terminal blocks · 4 mm ² · screw	UT 4-MT, UT 4-MT BU, UT 4-TG-P/P, UT 4-MT-P/P, UT 4-TG	—	—	—	—	—
Disconnect and test terminal blocks · 4 mm ² · spring	PTME 4	—	—	—	—	—
Disconnect and test terminal blocks · 5 mm ² · screw	UK 5-MTK-P/P, UK 5-MTK-P/P BU	—	—	—	—	—
Disconnect and test terminal blocks · 6 mm ² · n/s	UTTB 4-MT	—	—	NSYTRV62TTD	—	—
Disconnect and test terminal blocks · 6 mm ² · push-in	PTME 6	—	—	—	—	—
Component terminal blocks · 2.5 mm ² · n/s	UTTB 2,5-DIO/U-O, UTTB 2,5-2DIO/O-UL/UR-UL, UTTB 2,5-DIO/O-U	—	—	—	—	—
Component terminal blocks · 2.5 mm ² · push-in	PT 2,5-TWIN-DIO/L-R, PTTB 2,5-2DIO/O-UL/O-UR, PT 2,5-DIO/L-R, PTTB 2,5-DIO/U-O, PT 2,5-QUATTRO-DIO/R-L	—	—	—	—	—
Component terminal blocks · 2.5 mm ² · screw	UTTB 2,5-2DIOULOUR	—	—	—	—	—
Component terminal blocks · 2.5 mm ² · spring	STTB 2,5-DIO/O-U	—	—	—	—	—
Component terminal blocks · 4 mm ² · push-in	PT 4-QUATTRO-DIO 1N 5408/R-L	—	—	—	—	—
Component terminal blocks · 4 mm ² · screw	UT 4-MTD-DIO/R-L, UT 4-MTD-DIO/L-R	WDUL 4/5K	—	—	—	—

Part numbers and designations are those of the original manufacturers and are given for identification. cBallast is an independent supplier. © cBallast 2026 · cballast.com