



Pressure PN	Tube O.D.		Order-Code
	D1	D2	
Series LL			
100	6	4	GRV-LL-06/04-OMD
100	8	6	GRV-LL-08/06-OMD
Series L			
500	8	6	GRV-L-08/06-OMD
500	10	6	GRV-L-10/06-OMD
500	10	8	GRV-L-10/08-OMD
400	12	6	GRV-L-12/06-OMD
400	12	8	GRV-L-12/08-OMD
400	12	10	GRV-L-12/10-OMD
400	15	6	GRV-L-15/06-OMD
400	15	8	GRV-L-15/08-OMD
400	15	10	GRV-L-15/10-OMD
400	15	12	GRV-L-15/12-OMD
400	18	8	GRV-L-18/08-OMD
400	18	10	GRV-L-18/10-OMD
400	18	12	GRV-L-18/12-OMD
400	18	15	GRV-L-18/15-OMD
250	22	8	GRV-L-22/08-OMD
250	22	10	GRV-L-22/10-OMD
250	22	12	GRV-L-22/12-OMD
250	22	15	GRV-L-22/15-OMD
250	22	18	GRV-L-22/18-OMD
250	28	10	GRV-L-28/10-OMD
250	28	12	GRV-L-28/12-OMD
250	28	15	GRV-L-28/15-OMD
250	28	18	GRV-L-28/18-OMD
250	28	22	GRV-L-28/22-OMD
250	35	15	GRV-L-35/15-OMD
250	35	18	GRV-L-35/18-OMD
250	35	22	GRV-L-35/22-OMD
250	35	28	GRV-L-35/28-OMD
250	42	15	GRV-L-42/15-OMD
250	42	18	GRV-L-42/18-OMD
250	42	22	GRV-L-42/22-OMD
250	42	28	GRV-L-42/28-OMD
250	42	35	GRV-L-42/35-OMD