


VOLA HV1, HV3, HV4

Fitting instruction
Montageanleitung
Monteringsvejledning
Monteringsvægledning
Montage hanleiding
Manuel de montage



HV1, HV3:
04/00020
04/00028










www.vola.com

HV1/HV3/HV4_V4_40999827



HV1, HV3	L	H	h
Std.:	114 mm 4 1/2"	120 mm 4 3/4"	27 mm 1"
+30:	114 mm 4 1/2"	150 mm 6"	56 mm 2 1/4"
/150:	150 mm 6"	120 mm 4 3/4"	27 mm 1"
+30/150:	150 mm 6"	150 mm 6"	56 mm 2 1/4"
+170:	114 mm 4 1/2"	290 mm 11 1/2"	197 mm 7 3/4"
+170/150:	150 mm 6"	290 mm 11 1/2"	197 mm 7 3/4"





5

Data, 3 Bar/43.5 Psi:

	Max.	l/min.	Gal/min.	Note.
HV1/3:	5.0	1.3		Standard
HV1/3:	4.5	1.2		Standard USA
HV1/3:	9.0	1.8		Standard Japan
HV4	9,0	1.8		


Max. 70°C, 158°F

HV1


HV3

HV4

2




HV1: Ø10
HV1JP: Ø10
HV1US: Ø3/8"
HV1Q: Ø3/8"



HV1US:

480 mm

9/16"



VR277K:	VR22, VR269, VR277
*VR17L4K:	VR15P, VR16L4, VR17L (US-Standard)
*VR17L5K:	VR15P, VR16L5, VR17L (Standard)
*VR17L9K:	VR15P, VR16L9, VR17L (Japan Standard)
*VR17LSK:	VR15P, VR16LS, VR17L
VR297/L/M:	VR20, VR22, VR269, VR273/L/M, VR277, VR294, VR295, VR296
VR433:	VR261, VR263, VR440, VR442, 2xVR444
NR.10/L/M:	VR20, VR22, VR273/L/M, VR294, VR295



vola®

Lunavej 2
DK-8700 Horsens
Tlf : + 45 7023 5500
sales@vola.com
www.vola.com

VOLA HV1

Date
Okt. 16

Rev.
6

Sheet
SB 21.1