



Montageanleitung Assembly instructions
drylin®

LINEAR ROBOT




Raumportal – DLE-RG-0001
Room gantry – DLE-RG-0001







DLE-A-RG-0001-Z-XXX 1x




DLE-A-RG-0001-AC-X2-XXX 1x



DLE-A-RG-0001-AC-X1-XXX 1x




AK-0021 1x



DLE-A-RG-0001-Y 1x






ETY-104001 2x





AWMP-10 1x




COU-AR-K-100-100-32-32-B-AAAA 2x

	NOR-10517	4x
	NOR-10526	4x
	NOR-10617	4x
	NOR-10606	4x
	ZLW-1040-75.40 ZLW	4x








1






2






3




4




5



6




7





control


8




9














12




13



14





15






control

16






DLE-RG-0001 INI Kit

optional







DLE-RG-0002 INI Kit

optional







DLE-RG-0003 INI Kit

optional






DLE-RG-0004 INI Kit


optional



DLE-RG-0012 INI Kit

optional







igus® GmbH
Spicher Str. 1a
51147 Köln Cologne
Tel. +49 2203 9649-145
Fax +49 2203 9649-334
info@igus.de
www.igus.de
www.igus.eu

© igus® GmbH

Herausgeber ist die igus® GmbH, Deutschland
Published by igus® GmbH, Germany
MAT0075813.25 Stand Issue 09/2025
Technische Änderungen vorbehalten
Subject to technical alterations