

INTENDED USE

Pair of brackets to support circular or rectangular HVAC ducting directly to Mekano® channels or frames.

Suitable for both insulated and non-insulated ducting.

For rectangular ducting in widths over 1 m, an extra support should be considered to avoid the ducting sagging in the centre.

INSTRUCTION FOR USE

Decide the position of the brackets according to the ducting width, and attach using self locking bolts (not supplied). Adjust as necessary and tighten securely.



The channel can be insulated from the brackets by applying insulation pads or tape to the contact points, or using optional Strap-bracket pads.

Attach the ducting to the brackets using proprietary straps (not supplied), for example levasint coated type Band-it AE-416 / AE436 with lock 456.



User Guide for Bolts:
Recommended Torque

Shown without optional insulation pads.



Optional insulation pads are available, suitable for both circular or rectangular ducting.

